

1 Audit (programme 7)

Only the master can perform the audit function.
The audit can only be read out via iButton.

			✓	✗
1.	Disconnect the cable of the input unit from the lock.			
2.	Connect the iButton-reader to the input unit`s interface.			
3.	Press the iButton into the iButton-reader.		■ ■	■ ■ ■
4.	Press and hold the key "7" until the red LEDs flash permanently.	7	■ ■	■ ■ ■
5.	Enter your 7-digit master code e.g.	1 2 3 4 5 6 7	■ ■	■ ■ ■
6.	Wait until an acoustic signal occurs twice. The iButton is written on.		■ ■	
7.	Remove the iButton and press it into the iButton-reader on the PC.			
8.	Start the Software „DIALOG“ at the PC.			
9.	In the programme choose the button „Read“. The audit will be read out.			
10.	Proceed with the audit as described in „2 Audit-Software“.			
11.	In the programme choose the button „Quit“ for leaving the programme.			

2 Audit-Software

- The last 100 events will be saved in chronological order and read out via the iButton. Event 1 is always the current event. The events are protocolled without date and time.
- With the button "Save" the whole protocol can be exported as text file and imported into other software tools (Excel) for further examination.
- With the button "Load" saved protocols can be read.
- With the button "Print" the whole protocol can be printed by the installed standard printer.